

TABLEROS CONTRAINCENDIO



COMPONENTES:

01 GABINETE METALICO CON PINTURA ELECTROSTICA	COLOR ROJO	
01 INTERRUPTOR TERM. CAJA MOLDEADA PRINCIPAL		LS
01 INTERRUPTOR TERM. 2 X 10 CIRC. DE CONTROL.		LS
02 CONTACTORES CATEGORIA AC3 - TRIANGULO	BOMBA PRINCIPAL	LS
01 RELE TERMICO REGULABLE CONTRA SOBRE CARGA	BOMBA PRINCIPAL	LS
01 CONTACTORES CATEGORIA AC3 - ESTRELLA	BOMBA PRINCIPAL	LS
02 SELECTORES DE CONMUTACION MAN 0 AUT.		SALTZER
01 GUARDA MOTOR REGULABLE DE PROTECCION	BOMBA JOCKEY	LS
01 CONTACTORES CATEGORIA AC3	BOMBA JOCKEY	LS
07 BORNERA DE CONTROL AUTOMATICO Y BAJO NIVEL.		LS
PILOTOS INDICADORES DE: FUNCIONAMIENTO, SOBRE CARGA, BAJO NIVEL Y TABLERO ENERGIZADO.		

BCI10HP BJ3HP → BCI 10HP=Potencia Bomba Principal, BJ3HP = Potencia Bomba Jockey.

<u>MODELO</u>	<u>AMP MAX</u>	<u>AMP. DE SOFT STARTER.</u>
BCI10HP BJ3HP	32AMP	32 AMP
BCI12.5HP BJ3HP	38AMP	38 AMP
BCI15HP BJ3HP	47AMP	45 AMP
BCI20HP BJ3HP	64AMP	63 AMP
BCI25HP BJ3HP	80AMP	72 AMP
BCI30HP BJ3HP	100AMP	80 AMP
BCI40HP BJ4HP	130AMP	106AMP
BCI50HP BJ4HP	160AMP	
BCI60HP BJ4HP	185AMP	
BCI75HP BJ4HP	210AMP	